



CONNECTORS	JUMPERS
J1: Power supply 1: +5V 2: GND	J1: reset JP2-3: Op. mode JP3 JP2
J2: TTL serial port 1: TXD 1: RXD 1: GND	Mode #0 OFF OFF Mode #1 OFF ON Mode #2 ON OFF Mode #3 ON ON
J3: RS232C serial port 1: TXD 2: RXD 3: GND	

